



Phone: (516) 868-4411 Fax: (516) 868-4609


Website: primelite-mfg.com Email: sales@primelite-mfg.com

GOOSENECK SIGN LIGHT ASSEMBLY INSTRUCTIONS



- 1. Feed the wire from the shade through the gooseneck arm.
- 2. Twist the shade onto the arm's thread at least 3 turns and tighten the set screw.
- 3. Tighten the conduit nut over the arm's threads Be sure to fit the O ring into the groves





4" diameter die cast

canopy 1/2" thread

- 4. Connect the power box wires with the appropriately-colored accompanying wires provided green with green, white with white, black with black.
- 5. Wire nuts are not provided.
- 6. Place gasket between the mounting canopy and the junction box.
- 7. Using the 10/24 screws provided, secure the canopy to the junction box. Use all four screws.